MOST COMMONLY ASKED QUESTIONS SIERRA LCD

1. To arm the system – wait until the codepad reads 'READY' then enter your 'CODE'

2. To disarm the system – enter your 'CODE'

3. To cancel an alarm – press 'CANCEL' then enter your 'CODE'

4. To reset the alarm memory – hold down 'CANCEL' for 2 seconds

5. To bypass a zone – press 'BYPASS' then 'ZONE NO' (2 digit) then enter your 'CODE'

6. If the Service light is on – hold 'SERVICE' (Number 3 Key) for 2 seconds and the keypad will display the nature of the fault.

Control Room phone number – 1300 138 050

24 Hour Emergency Service 0418 955 992

IF IN DOUBT REFER TO YOUR USER BOOKLET